

SIMATIC S7, F-programming tool, STEP 7 Safety Basic V16, Upgrade V13 SP1..V15 > V16; for parallel usage of STEP 7 Safety Basic V13SP1..V15.1 and STEP 7 Safety Basic V16; engineering software; Upgrade license for 1 user; license key on USB stick Class A, 2 languages (de, en); executable with TIA Portal V16 STEP 7 Basic V16 or higher; for configuration of SIMATIC S7-1200F
***** Content: 1x USB



last modified:

01/24/2020